



**Brembo 328MM Front Brake Kit
02-> Audi A4
Part # 1A1.6020A**

Glue this page onto cardboard and cut out the shaded template at right.

Place template on back of front wheel as shown in picture below. Distance between the template and the wheel spokes, at point A, must be at least 1mm for proper clearance.

Also check clearance between template and wheel rim at point B. Pay close attention to rivets or valve stems all the way around the inside circumference of the wheel in this area. There must be at least 1mm distance for proper clearance.

